

Overhead Drum Carrier / Tilter Operating Instructions



Model DCT-75

IMPORTANT

1. Please read all instructions **THOROUGHLY** before attempting to operate your new drum carrier / tilter.
2. The model **DCT-75** has a maximum capacity rating of 800 pounds (363 kilograms) with a full drum and 500 pounds (227 kilograms) with a half-full drum. This product is intended for lifting and tilting drums of size and type noted above. **DO NOT** exceed these ratings as the unsafe condition that may result could cause damage, excessive wear, or make the product awkward to handle.
3. When operating, loading, unloading or maintaining your drum carrier / tilter, always have good footing and a firm hold while using care and good judgment at all times. Keep hands, loose clothing, etc. clear and away from all moving parts. Never allow anyone to be below any part of a raised drum carrier / tilter or drum. Read operating instructions before operation.

OPERATING INSTRUCTIONS

1. Securely attach overhead hoisting hook to loop of drum carrier / tilter.
2. Ensure carrier / tilter saddle is in the horizontal position before loading or unloading drum.

3. Open carrier / tilter saddle completely.
4. Lock drum in place by cinching chain with ratchet tightener.
5. Ensure drum is in the vertical position for safe transportation.
6. *To pour contents of drum:* Pull on chain to rotate drum to angle required to pour contents. For best control of drum pouring angle, pay out one side of the chain loop while pulling in the other side.
7. After pouring, rotate drum back to vertical position for safe transportation.

CAUTION !

- **DO NOT** exceed rated weight capacity of 800 pounds (363 kilograms) with a full drum and 500 pounds (227 kilograms) with a half-full drum.
- **ALWAYS** transport drum in the vertical position.
- **DO NOT** allow drum to impact on floor, ground, dumping station, etc. for possible damage to drum and / or drum carrier / tilter.

MAINTENANCE

1. Lubricate gear-train once a month with a high-grade oil.
2. Oil saddle hinges, ratchet, pawl, chain and other moving parts periodically.
3. Periodically inspect all moving parts, framework and contact areas for signs of wear, fatigue or loosening. Tighten, adjust or replace parts as necessary to prevent failure and maintain proper function.

LIMITED WARRANTY

Vestil Manufacturing Corporation (“Vestil”) warrants this product to be free of defects in material and workmanship during the warranty period. *Our warranty obligation is to provide a replacement for a defective original part if the part is covered by the warranty, after we receive a proper request from the warrantee (you) for warranty service.*

Who may request service?

Only a warrantee may request service. *You are a warrantee if* you purchased the product from Vestil or from an authorized distributor AND Vestil has been fully paid.

What is an “original part”?

An original part is a part used to make the product as shipped to the warrantee.

What is a “proper request”?

A request for warranty service is proper if Vestil receives: 1) a photocopy of the Customer Invoice that displays the shipping date; AND 2) a written request for warranty service including your name and phone number. Send requests by any of the following methods:

Mail
Vestil Manufacturing Corporation
2999 North Wayne Street, PO Box 507
Angola, IN 46703

Fax
(260) 665-1339
Phone
(260) 665-7586

Email
sales@vestil.com

In the written request, list the parts believed to be defective and include the address where replacements should be delivered.

What is covered under the warranty?

After Vestil receives your request for warranty service, an authorized representative will contact you to determine whether your claim is covered by the warranty. Before providing warranty service, Vestil may require you to send the entire product, or just the defective part or parts, to its facility in Angola, IN. The warranty covers defects in the following *original* dynamic components: motors, hydraulic pumps, electronic controllers, switches and cylinders. It also covers defects in *original* parts that wear under normal usage conditions (“wearing parts”): bearings, hoses, wheels, seals, brushes, batteries, and the battery charger.

How long is the warranty period?

The warranty period for original components is 90 days. The warranty period begins on the date when Vestil ships the product to the warrantee. If the product was purchased from an authorized distributor, the period begins when the distributor ships the product. Vestil may extend the warranty period for products shipped from authorized distributors by *up to* 30 days to account for shipping time.

If a defective part is covered by the warranty, what will Vestil do to correct the problem?

Vestil will provide an appropriate replacement for any *covered* part. An authorized representative of Vestil will contact you to discuss your claim.

What is not covered by the warranty?

1. Labor;
2. Freight;
3. Occurrence of any of the following, which automatically voids the warranty:
 - Product misuse;
 - Negligent operation or repair;
 - Corrosion or use in corrosive environments;
 - Inadequate or improper maintenance;
 - Damage sustained during shipping;
 - Collisions or other incidental contacts causing damage to the product;
 - Unauthorized modifications: DO NOT modify the product IN ANY WAY without first receiving written authorization from Vestil. Modification(s) might make the product unsafe to use or might cause excessive and/or abnormal wear.

Do any other warranties apply to the product?

Vestil Manufacturing Corp. makes no other express warranties. All implied warranties are disclaimed to the extent allowed by law. Any implied warranty not disclaimed is limited in scope to the terms of this Limited Warranty.

