

Recommended table top assembly

LAMINATE

Treston laminate tops assembled with wood screws provided.

PHENOLIC

DO NOT USE provided screws from the hardware pack provided with the table. These screws are for laminate work surfaces only.

Treston phenolic tops can be assembled in 2 ways:

- **Mechanical fasteners** - Screws to be provided by the installer. Pre-drill a pilot hole in the bottom of the work surface, taking care to keep from penetrating through the top. The pre-drilled hole should be the same length as the screw shaft. The screw should be slightly larger in diameter than the pilot hole. Use a coarse threaded screw, wood or machine.
- **Adhesive** - Provided by the installer. Use 100% silicon. Apply several "spots" or a continuous bead to the top of the table frame. Position the work surface as centered on the frame and let cure for 12 hrs at room temp.

