

# Mobile Clear Room Divider

1. Connect the uprights to the bases using the flat head screws provided.
2. Connect the lower crossbar to the uprights using the round head screws provided. The lower crossbar has riveted tabs with a slotted hole.
3. Connect the upper crossbar to the uprights using the round head screws provided.
4. Slide the dowels through the pole pockets of the vinyl.
5. Insert the pole pockets with dowels into the channels of the crossbars.
6. Attach the end caps to the crossbars.
7. To add tension to the vinyl: Slightly loosen the bottom crossbar screws, gently pushing downward on the crossbar to create additional tension in the vinyl, then fully re-tighten the screws.

