

Components in the Box:

Α.

B.



Free Standing Feet



Acrylic Back Panel

PLEASE NOTE: Quantity of free standing feet (A) will vary depending on the size of the acrylic back panel (B).

Assembly Instructions:

- 1. Remove all components from the box.
- 2. Place free standing feet (A) anywhere on the acrylic back panel (B).
- 3. Place assembled free standing barrier in desired workplace location.

2.



3.



Completed Assembly:



