



STARTER UNIT



ADD-ON UNIT

1. Place 2 uprights on the floor facing each other as shown.



2. Fold down the struts located inside the uprights.



3. Bolt the struts through the facing uprights to join them together.



4. Join the channel base to the bottom of the 2 uprights.



5. Repeat steps 1-4 with the second pair of uprights.



6. Join the 2 pairs of uprights together by hooking the crossbeam in place.



7. Repeat step 6 at the top and the bottom of both the front and the back of the unit.



8. Secure each side of the crossbeam with a locking pin to keep it securely in place during use.



9. Hook each axle bracket at the desired height.



10. Place axles onto each pair of brackets.





**FINISHED
STARTER UNIT**

Add-On Assembly

1. Follow steps 1-4 from the starter unit assembly instructions.



2. Join the new upright pair with the starter unit by hooking crossbeams at the top and bottom of the front and back. Secure the crossbeams with locking pins.

**FINISHED
ADD-ON UNIT**

