



Closed Front and End Bases

1. Front and end bases must be attached before the locker foot is attached.
2. Bolt front and end bases in two places.
3. Anchor lockers as specified in locker assembly instructions.

