

We can supply that:


Manual del usuario **User's manual** Manuel de l'utilisateur **Customer Service** Servicio de atención al Cliente Service à la clientèle

US: 1-800-645-2986 US: 1-800-645-2986

Canada: 888-645-2986


Frame and Leg Kit for 48/60/72 Manual Hand Crank Adjustable Workbench - Black


Frame & Leg Kit Model: 493780BK



No.Description	Qty
1. Leg	1
2. Leg	
3. Foot	2
4. Glide	4
5. Crossbar Ends	2
6. Center Rails	2
7. Rotating Bar	1
8. Side Brackets	2
9. Handle Holder	1
10. Handlebar	
11. Short Rungs	2
12. Long Rung	
21. Machine Screws M6	x1024
22. Machine Screws M6	5x16 8
23. Wood Screws M5x1	610
24. Machine Screws M4	x64
25. Furniture Screws M	6x10 4
26. Butterfly Nut M6	4

Tools Needed









Phillips Head Screwdriver and/or Power Drill

Tape Measure

Components





- Requires 2 people for assembly.
- Ensure you are using proper PPE such as glove, steel toe boots, safety glasses.
- Perform regular inspections on the hardware by checking their tightness every 4 months.
- If table height isn't adjusting, remove items off table and inspect. Do not force adjustment.

Hardware






















Hand Crank Adjustable Workbench

1) Lay out all components and hardware to ensure that you have all the components and hardware. Fully separate the Crossbard ends (Ref 5). You will find the Crossbar Center Rails (Ref 6) Inside.




2) Prop up the assemblies from Step 1 As shown. Insert x4 M6*10 machine screws (Ref 21) through the holes of each Crossbar End (Ref 5) going into the Leg (Ref 1) and tighten the screws. Then connect the other Leg (Ref 2) with the other Crossbar End (Ref 5) in the same way.




3) Attach the Side Brackets (Ref 8) to the assemblies from Step 2, as shown. Insert two M6*10 Machine Scerws (Ref 21) through the two holes of the Side Bracket (Ref 8) going into the Crossbar End/Leg Assembly.


Repeat Step 3 with the other assemblies.



4) Slide the two Crossbar Center Rails (Ref 6) into the two Crossbar Ends (Ref 5)




5) Put the Rotating Bar (Ref 7) into the assemblies from step 4.




Hand Crank Adjustable Workbench

6) Place the table under the accessories and place it in the corect position. Then attach the Handle Holder (Ref 9) to the Table Board with x4 M5*16 wood screws (Ref 23) and tighten them.


Then connect the Table Board to the desk frame with x6 M5*16 wood screws (Ref 23) and tighten them.




7) Please insert 8 M6*10 machine screws (Ref 21) through the holes in each crossbar end (Ref 5) going into the Center Rails (REf 6) and tighten the screws. Then insert x2 M4*6 machine screws (Ref 24) into the Rotating Bar (Ref 7) and tighten as shown. Insert the Handlebar (Ref 10) into the Handle Holder (Ref 9). Then insert x2 M4*6 machine screws (Ref 24) into the Handle Holder (Ref 9) and tighten them.



8) Attach the Short Rungs (Ref 11) to the Leg with x4 M6*10 Furniture Scerws (Ref 25). Then attach the Long Rung (Ref 12) to the SHort Rungs (Ref 11) with x4 M6*16 Machine Screws (Ref 21) and x4 Butterfly Nut M6 (Ref 26).



9) Attach a foor (Ref 3) with x4 M6*16 machine screws (Ref 22) into each Legs and tighten screws. Connect x2 glides (Ref 4) together into each foot,



10) Turn the table over.