



## Instructions for an X-Base Table

6100 Hix Road • Westland, MI 48185  
(734) 722-1595 • Fax (734) 722-8210 • Toll Free (866) 883-2484  
www.premiermi.com

### Tools Needed:

18mm Socket or Wrench

Power Drill

### Part List (Found in base box)

- A. 1 Base
- B. 1 Cylinder Tube
- C. Threaded Rod (with welded nut on one end.
- D. Spyder 13" (fits on bottom of table)
- E. 8 Screws
- F. 4 Glides
- G. 1 Nut
- H. 1 Washer

1. Place table top upside down on the floor. (You will want to have 2 or more people).
2. Take nut off threaded rod (C). Put threaded rod (C) through spyder (D). The end of the threaded rod with fixed nut should be inside open area of spyder (D).
3. Place cylinder tube (B) over threaded rod (C). Cylinder tube (B) must be placed over 4 notches on top of spyder (D).
4. Turn spyder and cylinder upside down so that spyder is on a flat surface.
5. Place base (A) over threaded rod (C). Before you place washer (H) and nut (G) onto threaded rod (C) make sure cylinder tube (B) is in the center of base (A) and still in the middle of the 4 notches on spyder (D). Tighten nut (G) onto threaded rod (C) and attach base (A). Tighten securely.
6. Place completed base assembly onto the bottom of the table and line up 8 screw holes. Insert all 8 screws (E) and tighten them down. Screw glides (F) onto bottom of base (A).
7. Turn table upright (You may want to use 2 or more people. Adjust 4 glides to level table.

**\*\*Please note there are 8 predrilled screw holes. These are only starter holes. If holes do not line up exactly, get at least two of the holes lined up, put screws in those holes and drill in the 6 screws.**

