



UPRIGHT

BIN HOLDER

3/8" STRUT NUT

3/8" X 1" ALLEN CAP SCREW

1) FASTEN BIN HOLDER TO UPRIGHTS AT DESIRED HEIGHT USING 3/8" X 1" ALLEN CAP SREWS AND 3/8" STRUT NUTS

PRO-LINE  
BIN HOLDER ASSEMBLY  
TO AN HD BENCH  
DRAWING #A7449