

Floor Standing Sanitizing Wipe Station Model no. 641563



Assembly Instructions

1. Fold down Left Side and Right Side along creases.
2. Fold unit in half along the creases in the middle.
3. Peel off protective film on small gray tabs and attach to the back of the top panel. Peel off the protective film on the long grey tabs and attach them to the inside of Left Side and Right Side panels respectively.
4. Open the back Door. Before installing the adhesive Shelf, use your wipe dispenser to measure the desired height position, and mark the inside. Fold Shelf tabs along creases and peel off the film on tapes and attach shelf to the marked height. Optional: Reinforce the shelf and install the optional shelf above the installed shelf.
5. Peel off the adhesive film on the header and attach it to the top back of the unit.
6. Place the wipe dispenser on the shelf and fold the door handle to keep the door closed.

