




MODEL 501 Standard Utility Cart

TOOLS REQUIRED:
(2) 7/16 wrenches or sockets



1 person assembly



STEP 1

Place frame upside down with caster mounting holes face up. Place raceway cover on caster and insert caster stem into mounting hole. Using two 7/16 wrenches, secure caster with two bolts and two nuts. Nuts should be facing toward inside of unit. Repeat for all four casters.



STEP 2

Place frame on floor with wheels facing down.



STEP 3

While lifting the long handle, hook one end of bottom shelf over support bar. Place other end of bottom shelf on support bar of opposite side of frame. Lower handle so frame spreads apart and locks bottom shelf into place.



STEP 4

Place top basket onto frame.

Your utility cart is ready to use.

WARNING



- Never allow anyone to ride in cart.
- Always proceed slowly.
- Be sure wheels roll freely and turn easily.
- Balance all loads in center of basket.
- Maximum load capacity 25 pounds.

HARDWARE INCLUDED (Not to scale)

x8 Nuts

x4 Raceway Covers

x8 Bolts

