


R&B WIRE PRODUCTS, INC.

YOUR TRUSTED PARTNER SINCE 1946






ASSEMBLY INSTRUCTIONS

100, 200, 201, 350 SERIES Wire Cart







Set base upside down with legs pointing up to install casters. Place raceway cover onto caster stem and insert caster stem into base leg. While holding raceway cover up against caster, insert a hex head bolt into each leg hole, and secure with nuts facing toward inside of unit. Repeat with remaining casters.






Place basket on base and align holes in bottom of basket with holes in top of base. Insert flathead bolts through hole in basket and through base, and secure with nuts. Tighten until bolt head engages nylon lock on nut.


NOTE: Your laundry cart is assembled and ready for use. If you purchased the Single Pole Rack or Double Pole Rack accessories, continue to page 2.



· Never allow children or adults to ride in or on cart, as it can cause serious injury or death. Be sure casters roll freely and turn easily. · Place all loads in center of basket for balance.



SALES@RBWIRE.COM



SALES@RBWIRE.COM

(800) 634-0555

RBWIRE.COM