

Customer Service
1-800-645-2986





Assembly
Instructions

**Child Size Round & Square Metal Mesh
Picnic Tables**

Model No. 262078K BL/BK/GN/RD/GY
277150K BL/BK/GN/RD/GY

Model No. 277151K BL/BK/GN/RD/GY
694551K BL/BK/GN/RD/GY



These Assembly instructions and Warnings should be retained by maintenance or safety department for future reference. Routine maintenance and inspection of the equipment should be performed every six months. Damaged and worn parts should be removed from service until replaced or repaired to prevent safety hazards.

⚠ WARNING ⚠

- Assembly and installation of equipment should be performed by 2 people.
- Workers should use OSHA approved safety and lifting equipment.

⚠ WARNING




- This product contains chemicals which are known by the state of California to cause cancer, birth defects or other reproductive harm.

⚠ WARNING ⚠

- Do not climb on, under or through tables and benches.
- Two people required to move tables and benches.
- Do not use if any parts of bench or table are broken or damaged.
- Inspect and tighten hardware every six months.
- Replace rusted hardware and damaged components.




Child Size Round Metal Mesh Picnic Tables



CONTENTS		
REF.	QTY.	DESCRIPTION
1	4	Right Leg
2	1	Top
3	4	Left Leg
4	1	Leg Support
H5	4	Bench
H1	28	M8 x 1,25 x 24mm Lg. Hex Bolt
H2	56	Plain Washer
H3	28	M8 x 1,25 Nylon Lock Nut


2

Child Size Round Metal Mesh Picnic Tables



3


Child Size Square Metal Mesh Picnic Tables



CONTENTS		
REF.	QTY.	DESCRIPTION
1	4	Right Leg
2	1	Top
3	4	Left Leg
4	1	Leg Support
H5	4	Bench
H1	28	M8 x 1.25 x 24mm Lg. Hex Bolt
H2	56	Plain Washer
H3	28	M8 x 1.25 Nylon Lock Nut

4

Child Size Square Metal Mesh Picnic Tables



5