

User's manual

Manual del usuario

Manuel de l'utilisateur



Customer Service
US: 1-800-645-2986


Servicio de atención al Cliente
US: 1-800-645-2986

Service à la clientèle
Canada: 888-645-2986

Mobile Reversible Whiteboard

Models: B444997, B444999, B1854285


Contents					
Ref.	Qty.	Description	Ref.	Qty.	Description
1	2	Side Frame	H6	2	Knob 
2	1	White Board	H7	5	# Self Tapping Phillips Wood Screw 
3	2	Connector Bar	H8	8	End Cap 
4	1	Tray	H9	6	Joint Cover 
H1	6	Joint Cover 	H10	1	6mm Hex Key 
H2	2	Swivel Caster 	H11	8	Plain Washer 
H3	2	Swivel Caster with Brake 		1	4 Hex Key with Phillips Head 
H4	1	Wrench 	2	Magnet 	
H5	8	M8 x 1.25 x 3mm Lg. Socket Head Screw 	4	Dry Erase Marker	
			1	Eraser	



Reversible Whiteboard

IMPORTANT:

Do not tighten screws and knobs until fully assembled



Reversible Whiteboard

IMPORTANT:

Tighten all screws and knobs
once unit is fully assembled

