

BULK CONTAINER


ASSEMBLY INSTRUCTION




www.globalindustrial.com

1-800-645-2986


CONTENTS

REF.	QTY.	DESCRIPTION	REF.	QTY.	DESCRIPTION	REF.	QTY.	DESCRIPTION
1	1	BASE	H1	8		H5	4	
2	4	POST	H2	40				
3	2	LONG SIDE	H3	16				
4	2	SHORT SIDE	H4	4				




NOTE:
if you purchased optional casters skip step 5.

5



6






www.globalindustrial.com

1-800-645-2986



BULK CONTAINER

OPTIONAL CASTER


ASSEMBLY INSTRUCTION

CONTENTS		
REF.	QTY.	DESCRIPTION
H1	16	
H2	4	

1



2







www.globalindustrial.com

1-800-645-2986

BULK CONTAINER

OPTIONAL LID

ASSEMBLY INSTRUCTION

CONTENTS		
REF.	QTY.	DESCRIPTION
1	1	LID
H1	2	
H2	2	
H3	8	
H4	2	