GLOBAL INDUSTRIAL™
We can supply that.®

User Manual	Manuel de l'Utilisateur
Customer Service US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

HIGH VELOCITY FLOOR FAN


Models
258324C

CAUTION

Read and follow all instructions before operating fan.
Do not use fan if any part is damaged or missing.

WARNING

- To reduce the risk of fire or electrical shock, do not expose to water or rain.
- To reduce the risk of fire or electrical shock, do not use this fan with any solid state speed control device.
- Automatically operated device - To reduce the risk of injury, disconnect from power supply before servicing.
- If the power supply cord is damaged, contact your local service centre or a qualified electrician to install an appropriate replacement cord to prevent any injury or damage.
- The appliance does not apply to be used in locations where special conditions prevail, such as the presence of a corrosive or explosive atmosphere (dust, vapour or gas).
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.



RULES FOR SAFE OPERATION:

- Never insert fingers or any other objects through the grill guard when fan is in operation.
- Disconnect the fan from its power source when moving from one location to another.
- Disconnect the fan from its power source when removing guards for cleaning.
- Be sure fan is on a stable, flat surface when in operation.
- Do not use fan in windows. Rain and moisture may create electrical hazard.
- Close supervision is necessary when this fan is used near children, the elderly and pets.
- Do not place the fan near an open flame, cooking or heating appliance, or hot surface.
- This fan should not be operated outside.

CAUTION: Do not alter the fan's assembly.
WARNING: Be sure that both front and rear guard screws are completely tightened in locking position before operation.

Model	Watts W			Amps A			Volts
	Low	Mid	High	Low	Mid	High	
258324	80	95	120	0.75	0.80	1.10	120V ~ 60Hz

OPERATING INSTRUCTIONS

TO ADJUST AIRFLOW UPWARD OR DOWNWARD: Tilt fan head to the desired angle. This high velocity fan can be used alone or in conjunction with air conditioning. Rotating the fan head upward serves to pull air from the floor and circulate it throughout the entire room.
SPEED CONTROL: Rotate SWITCH to LOW, MEDIUM and HIGH speeds for respective air velocity. It is normal for the motor to feel warm to touch after continuous operation. This fan features a thermostat that will automatically shut off should it overheat for any reason. If this happens, immediately unplug the fan from the outlet.

CLEANING

WARNING: Unplug from electrical supply source before cleaning.
1. Use soft damp cloth to clean, then wipe with dry cloth.
2. Do not use a cleaning solution that is harmful to paints or plastics.
3. Do not bend the blades.

Ventilateur de plancher à haute vitesse


Modèles
258324C

ATTENTION

Lire et suivre toutes les consignes d'utilisation avant de faire fonctionner le ventilateur. Ne pas utiliser le ventilateur si une partie de ce dernier manque ou est endommagée.

AVERTISSEMENT

Afin de réduire le risque d'incendie ou de choc électrique, ne pas exposer cet appareil à l'eau ou à la pluie. Afin de réduire le risque d'incendie ou de choc électrique, ne pas utiliser ce ventilateur avec un dispositif de contrôle de vitesse semi-constructeur. Cet appareil fonctionne automatiquement – Pour réduire le risque de blessure, débrancher de la source d'alimentation avant toute opération de réparation ou d'entretien. Si le câble d'alimentation est endommagé, contacter le centre de réparation le plus proche ou un électricien qualifié afin de faire installer un câble de remplacement adéquat afin de prévenir toute blessure corporelle ou dommage matériel.



CONSIGNES D'UTILISATION SÉCURITAIRE

- Ne jamais insérer les doigts ou un objet dans le grillage pendant que le ventilateur fonctionne.
- Débrancher le ventilateur de sa source d'alimentation avant de le déplacer.
- Débrancher le ventilateur de sa source d'alimentation avant de retirer les grillages pour le nettoyage.
- S'assurer que le ventilateur est posé sur une surface stable et plane pendant qu'il fonctionne.
- Ne pas utiliser le ventilateur dans les fenêtres. La pluie et l'humidité peuvent causer des risques d'électrocution.
- Il est essentiel de bien surveiller les enfants, les personnes âgées et les animaux se trouvant à proximité du ventilateur en marche.
- Ne pas poser le ventilateur à proximité d'une flamme nue, d'un appareil de cuisson ou de chauffage ou d'une surface chaude.
- Ne pas utiliser ce ventilateur à l'extérieur.
- **AVERTISSEMENT**: Ne pas modifier l'assemblage du ventilateur.

Modèle	Watt (W)			Ampères (A)			Volt
	Low	Mid	High	Low	Mid	High	
258324	80	95	120	0.75	0.80	1.10	120V ~ 60Hz

CONSIGNES D'UTLISATIONS

POUR ORIENTER LA CIRCULATION DE L'AIR VERS LE HAUT OU VERS LE BAS: Faire pivoter la tête du ventilateur à l'angle souhaité. Ce ventilateur à haute vitesse peut être utilisé seul ou avec un système de climatisation. Faire pivoter la tête du ventilateur vers le haut permet d'attirer l'air se trouvant sur la plancher pour le diffuser dans toute la pièce.

CONTRÔLE DE LA VITESSE: Faire tourner l'indicateur de vitesse à **LOW, MIDDLE OU HIGH** pour contrôler la vitesse de ventilation de l'air. Il est normal que le moteur soit chaud au toucher après une utilisation continue. Ce ventilateur est muni d'un thermostat qui mettra automatiquement le ventilateur en veille s'il surchauffait, peu importe la raison. Si cela se produit, débrancher immédiatement le ventilateur de la prise.

NETTOYAGE

AVERTISSEMENT: Débrancher de la source d'alimentation avant de nettoyer.

- Utiliser un linge doux et humide pour nettoyer. Essuyer ensuite avec un linge sec.
- Ne pas utiliser de solution nettoyante pouvant représenter un risque pour les peintures ou les matières plastiques.
- Ne pas plier les lames.