



THE BRAKE RELEASER DEICER TURBO DELIVERY SYSTEM

A safe, speedy alternative to the ol' pour and spill into the glad-hand. The Brake Releaser by Milton allows for a controlled burst of deicing solution. Designed as a backup to the cab's heater where frigid conditions can still freeze up lines, The Brake Releaser uses the trailer's air supply to deliver a powerful stream - dissolving ice crystals built up in the truck's brake lines



The Brake Releaser Standard Kit

- The Brake Releaser Unit
- 45-Degree Outlet
- Straight Outlet
- Instruction Manual



How to Use:



Install the Brake Releaser

- Evacuate air from trailer brake system
- Disconnect emergency line glad hand from trailer
- Attach the Brake Releaser to the trailer glad hand
- Connect tractor emergency glad hand to the Brake Releaser
- For best results, make sure Brake Releaser sits level

Add De-icing Fluid to Frozen Brake Lines

- Remove Brake Releaser lid from bowl
- Pour the appropriate deicing solution for your trailer's brake system into the Brake Releaser bowl and replace lid
- Turn valve to the "open" position
- Move to cab and engage the trailer air supply to send deicing fluid to frozen brake lines
- Turn valve to the "closed" position

Uninstall the Brake Releaser

- Move to cab and evacuate air from trailer brake system
- Relieve pressure from the bowl
- Detach the Brake Releaser from tractor and trailer glad hand connections
- Reconnect emergency line to trailer, and you're on your way

