

User's manual

Manual del usuario

Manuel de l'utilisateur

Customer Service
US: 1-800-645-2986

Servicio de atención al Cliente
US: 1-800-645-2986


Service à la clientèle
Canada: 888-645-2986

Aluminum Pallet Dolly with Tilt Rollers

Models: 800500, 800501, 800502

PACKAGE CONTENT

Part	Qty
Pallet Dolly	1
Ratchet Strap	2
Pull Rod	1





SPECIFICATION

Model no.	Load cap.	Roller qty	Size
800500	4000 lb.	6	36" x 36"
800501	6000 lb.	8	48" x 42"
800502	8000 lb.	10	48" x 48"


ASSEMBLY

1. Position the dolly with the roller side on the floor.

2. Insert the spring locking ends into the slotted holes.
NOTE: The slotted holes are located in mirror sides of the dolly.



3. Repeat step two on the mirror side.




4. Feed the strap through the ratchet until tight.



5. Ratchet back and forward to tighten the excess strap.

6. Once tight, close the ratchet. Tie off the excess strap to prevent dragging.



7. Attach the pull rod to the eye-bolt.

