




User Manual	Manual de Usuario	Manuel de l'Utilisateur
Customer Service US: 1-800-645-2986	Servicio de atención al Cliente US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

Rechargeable Patio Umbrella Light with USB Cable, 36 LED Lights

Model: 436971



Items		
Ref.	Qty.	Description
Umbrella Light	1	
USB Charging Cable	1	

- ① Adjustable Clamp
- ② Indicator Light
- ③ ON/OFF Button DC
- ④ Socket
- ⑤ Light Source
- ⑥ OPEN Toggle Clip

Set up Instructions

Powered by USB cable

Insert the included USB cable into the DC Socket, then connect it to the USB port.

Powered by Batteries

Place three AA alkaline batteries in the battery slot.

Umbrella Setup

Open the OPEN Toggle Clip and clamp it to your umbrella with the built-in auto adjustable clamp. Close the OPEN Toggle Clip to fix it in place.

Operating Instructions

1 click: 100% brightness
2nd click: 50% brightness
3rd click: Off

Spec Sheet	
Spec.	Value
Light Source	36 LEDs
Power	1.5W
Color Temp.	8000K
Color	Black
Input Voltage	DC 5V/1A
Battery	AA 1.5V x 3

NOTED

Do not disassemble, or modify the item.
Do not allow rain or water to make contact with the item.
Load batteries in correct orientation.
Only use suggested battery capacity.
Clean light with soft cloth. Do not use chemicals.