



Carton Sizer


OPERATING INSTRUCTIONS




Adjust carton sizer to desired depth.



With top of box open, place carton sizer on the edge of box. Score the inside of the box around all four sides.



Cut all four corners of the box down to score.



Fold in flaps.