| Assembly Instructions	Instrucciones de Ensamblaje	Directives d'assemblage
Customer Service US: 1-800-645-2986	Servicio de atención al Cliente US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

Interion® Desk Shell

48"W x 24"D: 695931MH, 695931MC, 695931GY

Hardware & Tools		
Ref.	Qty.	Description
A	11	
B	11	
v	12	M8X40
D	11	
E	5	30X45X2
F	30	#8X5/8
G	4	M6X25
H	2	
I	1	Wrench

⚠ **NOTE**

- Do not use power drill in Part A.
- 2 people are requried to assemble and move desk.
- Assemble laminate boards on a smooth surface, such as a rug or capet, in order to prevent the board from being scratced.
- Inspect item carefully for missing parts or damage.
- Do not assemble if parts are missing or damaged.
- During assembly, keep hardware away from children.

IMPORTANT:
FUNCTION OF KLIX CAM

1/4 RIGHT TURN FOR

LOCKING Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole

Assembly Instructions	Instrucciones de Ensamblaje	Directives d'assemblage
Customer Service US: 1-800-645-2986	Servicio de atención al Cliente US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

Interion® Desk Shell

60"W x 30"D: 695932MH, 695932MC, 695932GY

Hardware & Tools

| Ref.	Qty.	Description
A	13	
B	13	
v	10	M8X40
D	13	
E	5	30X45X2
F	30	#8X5/8
G	4	M6X25
H	2	
I	1	Wrench

⚠ **NOTE**

- Do not use power drill in Part A.
- 2 people are requried to assemble and move desk.
- Assemble laminate boards on a smooth surface, such as a rug or capet, in order to prevent the board from being scratced.
- Inspect item carefully for missing parts or damage.
- Do not assemble if parts are missing or damaged.
- During assembly, keep hardware away from children.

IMPORTANT:
FUNCTION OF KLIX CAM

1/4 RIGHT TURN FOR

LOCKING Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole

a

A
B C
D

b

E F

g

interion®

globalindustrial.com
1.800.645.1232

| Assembly Instructions	Instrucciones de Ensamblaje	Directives d'assemblage
Customer Service US: 1-800-645-2986	Servicio de atención al Cliente US: 1-800-645-2986	Service à la clientèle Canada: 888-645-2986

Interion® Desk Shell

71"W x 36"D: 695933MH, 695933MC, 695933GY

⚠ **NOTE**

- Do not use power drill in Part A.
- 2 people are requried to assemble and move desk.
- Assemble laminate boards on a smooth surface, such as a rug or capet, in order to prevent the board from being scratced.
- Inspect item carefully for missing parts or damage.
- Do not assemble if parts are missing or damaged.
- During assembly, keep hardware away from children.

IMPORTANT:
FUNCTION OF KLIX CAM

1/4 RIGHT TURN FOR

LOCKING Make Sure The Arrow Is Pointing Upwards Before Inserting Into The Panel's Hole