




RAILEX AREA GUARDS ASSEMBLY INSTRUCTIONS

The Railex Area guards are shipped with all the components pre-cut and ready for assembly. All you need to assemble your area guard is shown below.


Please check that you have all the components before you start the assembly. The only tool you need for the assembly of your Area Guard is a 9/16" wrench.



Part Number	A- Horizontal Tube	B- Vertical Tube	C - Polymer Shield	3 Way Clamp	Welded Base	Locking 4" Caster	Standard 4" Caster	Finish
1350-1W4T-G-F	12-1/2"	68-3/4"	14-3/4" x 48"	K-3	1	2	2	Galvanized
1350-1W4T-B-F	12-1/2"	68-3/4"	14-3/4" x 48"	K-3	1	2	2	Black
1350-2W4T-G-F	21-1/2"	68-3/4"	23-3/4" x 48"	K-3	1	2	2	Galvanized
1350-2W4T-B-F	21-1/2"	68-3/4"	23-3/4" x 48"	K-3	1	2	2	Black
1350-4W6T-G-F	45-3/4"	68-3/4"	48" x 72"	K-3	1	2	2	Galvanized
1350-6W6T-G-T	69-3/4"	68-3/4"	72" x 48"	К-З	1	2	2	Galvanized

See separate instructions for the Cantilever Models.





Fully welded base

Part Number	A- Horizontal Tube	B- Vertical Tube	C - Polymer Shield	3 Way Clamp	Welded Base	Locking 4" Caster	Standard 4" Caster	Finish
1350-3W6T38-G-C	37-3/4"	68-3/4"	40" x 36"	K-3	1	1	2	Galvanized
1350-3W6T38-B-C	37-3/4"	68-3/4"	40" x 36"	K-3	1	1	2	Black
1350-3W6T48-G-C	37-3/4"	79-1/4"	40" x 36"	K-3	1	1	2	Galvanized
1350-3W6T48-B-C	37-3/4"	79-1/4"	40" x 36"	K-3	1	1	2	Black

Model 38 is 38" from underneath the cantilever to the floor

Model 48 is 48" from underneath the cantilever to the floor