

User's manual
Manual del usuario
Manuel de l'utilisateur
Customer Service
 US: 1-800-645-2986


Servicio de atención al Cliente
 US: 1-800-645-2986

Service à la clientèle
 Canada: 888-645-2986







6' Recycled Plastic Heritage Bench

Models:
B264201: Cedar
B264298: Gray
B264197: Green

Tools for assembly: Powered Driver , Phillips head bit,
 Ratchet Wrench, 11/16" Socket.



CONTENTS

REF.	QTY.		REF.	QTY.	DESCRIPTION
Bench Ends	2		Hex Head Bolts 1-1/2" Long Screws 1-1/4" Long Screws Concrete Anchors	4 4 36 4	
Support Rods	2		Bullnose Slats	2	
Back & Seat Brace	2		Seat & Back Slats	7	



Before you begin: Check components to verify all are included. Assembly will require two people and must be performed on a level and smooth surface. Do not overtighten hardware as damage can occur.




Illustration 'A'

Step 1

Loosely attach support rods to side frames using hex head bolts. See illustration "A".




Illustration 'B'

Step 2

Place the seat & back braces equally spaced on the cross support rods, see illustration "B". Note - it is necessary for a second person to assist with this step as braces will not stand up on their own.

Plastic Heritage Bench




Illustration 'C'

Step 3a

Position the front bullnose seat slat with the rounded edge facing out in the slots of each bench end. See illustration "C".




Illustration 'D'

Step 3b

Continue inserting the seat slats in the bench ends. See illustration "D".




Illustration 'E'

Step 3c

Insert the back slats, the final top slat will be the bullnose with the rounded edge facing up. With all slats in place, tighten the hex head bolts each bench end previously installed. See illustration "E".




Illustration 'F'

Step 4

Attach the back & seat braces to the backside of the slats using 1-1/4" screws at the pre-drilled holes or slots of the braces. Secure the bench ends to the upper and lower bullnose slats with the 1-1/2" screws through the pre-drilled holes of the sides frames. See illustration "F".

The assembled bench can be securely fastened to a solid surface using the included wedge anchors for concrete or other appropriate hardware.